

Network Safeworking Rules and Procedures

Shunting and Marshalling

Rule Number: 4013

Arc Infrastructure maintains the master for this document and publishes the current version on the Arc Infrastructure website. All changes and updates to the Network Safeworking Rules and Procedures are authorised by the Arc Infrastructure Rule Book Committee. This document is uncontrolled when printed.

Table of Contents

1.	Purpose	3
2.	General	3
2.1	Shunting	3
2.2	Marshalling	3
3.	Planning Shunting	4
3.1	Shunting Over Points	4
4.	Directing Shunting	5
5.	Running Lines	5
6.	Level Crossings	5
6.1	Loading or unloading under power	6
7.	Attaching Locomotive	6
8.	Detached Rail Vehicles	6
9.	Vehicles Under Repair	6
10.	Stabling Rail Traffic	7
10.1	On Running Lines	7
10.2	In Station Limits	7
10.3	In Sections	7
11.	Marshalling Irregularity	7
12.	Restoring Equipment	7
13.	References	8
14.	Effective Date	8

1. Purpose

The purpose of this rule is to prescribe the rules for safe *Shunting* and *Marshalling* in the *Network*.

2. General

Vehicles must not be *Shunted* in the *Network* without a *Motive Power Unit* attached (i.e. loose-*Shunted*).

2.1 Shunting

Shunting is moving Rail Traffic:

- to arrange or rearrange vehicle order in a Consist,
- to attach or detach vehicles from a Consist;
- to move vehicles in a yard or terminal; or
- to or from Running Lines, except for through Rail Traffic movements.

Shunting must be performed at a speed not exceeding Restricted Speed.

When performing *Shunting*, *Rail Traffic* may only be moved with the *Authority* of the *Competent Worker* directing the *Shunting* operations.

Workers not involved in Shunting must stay Clear of moving vehicles.

2.2 Marshalling

Vehicles carrying *Dangerous Goods* must be *Marshalled* in accordance with the <u>Australian</u> Code for the Transport of Dangerous Goods by Road and Rail (ADG Code)©.

3. Planning Shunting



WARNING: If there are narrow *Track* clearances, *Competent Workers* performing *Shunting* must keep at least 2 metres between themselves and moving vehicles.

When planning Shunting the Competent Worker directing Shunting operations must:

- confer with the Network Controller and agree about planned movements;
- confer with the Rail Traffic Crew and other Competent Workers and agree about planned movements; and
- warn other Competent Workers of hazards presented by narrow Track clearances, such as:
 - gates and fences;
 - buildings;
 - Platforms; and
 - rail vehicles on Adjacent lines.

Competent Workers during Shunting operations must:

- if necessary, arrange for clearance of Fixed Signals;
- make sure that Routes are correctly set and safe for movements; and
- make sure that it is safe to Shunt.

Competent Workers must tell the Network Controller when Shunting within their area of control has been completed.

3.1 Shunting Over Points

If the *Competent Worker* directing *Shunting* is not assured that the *Points* will hold their set positions, the *Points* must be *Secured* for the intended *Route*.

4. Directing Shunting

A Competent Worker directing Shunting must:

- make use of radio, light or Hand Signals to Communicate Effectively with the Competent Workerat the controls of the Motive Power Unit;
- be in a position where the safe progress of the movement and the line ahead can be seen; and
- closely accompany or ride in or on the leading vehicle in a position designated as safe by the operator and approved by Arc Infrastructure.

Rail Traffic Crews and Competent Workers directing Shunting must communicate at agreed intervals.

If communication between a *Competent Worker* directing *Shunting* and the *Rail Traffic Crew* is interrupted, the *Rail Traffic Crew* must stop the movement immediately.

5. Running Lines

Rail Traffic must be loaded or unloaded on Main lines and Loops only with the approval from the Approved Operations Delegate.

Shunting on Running Lines must be Authorised by the Network Controller.

On Running Lines, vehicles being Shunted must be equipped with an operating continuous Airbrake.

Vehicles with defective brakes must be *Shunted* in accordance with *Arc Infrastructure*'s specific instructions (refer Rule 4003 Rail Traffic Integrity).

Level Crossings

A Shunting movement over a Level Crossing must:

- be directed by a Competent Worker,
- not be commenced unless the Level Crossing is Clear, or road and pedestrian traffic has stopped; and
- not be commenced before it is safe to do so.

Where provided, Active Control Level Crossing equipment must be operated.

Shunted vehicles Hauled or Propelled across a Level Crossing must have the continuous Airbrake throughout the Consist.



NOTE: The *Consist* of vehicles being *Shunted* must comply with *Arc Infrastructure*'s <u>Automatic Air Brake Instructions</u>.

6.1 Loading or unloading under power

Rail Traffic loading and unloading under power may foul level crossings only if approved by Arc Infrastructure's Operations Delegate and where prior advice has been given to and approved by the Local Authority and the person in charge of the loading/unloading facility ensures that appropriate road traffic management is in place.

7. Attaching Locomotive

After attaching a *Locomotive* to stationary vehicles, the *Rail Traffic Crew* must fully pressurise the brake pipe before releasing *Handbrakes*.

8. Detached Rail Vehicles

Vehicles must not be detached from a *Motive Power Unit*, or a continuous brake system, until they are Secured against unintended movement by the use of sufficient effective Handbrakes or other devices, in accordance with Rule 4003 Rail Traffic Integrity.

Detached vehicles must be Secured:

- where necessary, Clear of Adjacent lines;
- · Clear of Level Crossings; and
- inside Catch Points or Derailing Devices provided to prevent vehicles entering Running Lines.

The Rail Traffic Crew must advise the Network Controller of vehicles detached en-route.

9. Vehicles Under Repair

Vehicles with warning signs, flags or lights must not be moved or *Shunted* against or have other vehicles attached to them unless:

- the warning signs, flag or lights are removed by the workers who put them there;
- no work is being done on or near the vehicles; and
- it is safe to move the vehicles.

10. Stabling Rail Traffic

10.1 On Running Lines

Rail Traffic may be Stabled on Running Lines only if:

- Derailing Devices are available;
- where Derailing Devices are not available, it has been Authorised by the Approved Operations Delegate;
- Advertised, when required;
- Unauthorised access to *Motive Power Unit* controls are prevented, and
- it is Secured against unintended movement.

10.2 In Station Limits

Where possible, when *Rail Traffic* is *Stabled* on a *Running Line* within *Station Limits*, the *Points* must be set to divert other *Rail Traffic* around the *Stabled Rail Traffic*.

10.3 In Sections

If the *Rail Traffic* is *Stabled* on the *Main Line* within a *Section*, the *Rail Traffic* must be treated as an *Obstruction* and *Protected* in accordance with Rule <u>4001 Protecting Disabled</u> Rail Traffic.

11. Marshalling Irregularity

If a *Marshalling Irregularity* is identified, the *Network Controller* and the *Rail Traffic Crew* must jointly arrange for the irregularity to be corrected.

12. Restoring Equipment

After completion of *Shunting*, a *Competent Worker* must restore *Points*, signals and other equipment to their normal position.

The Competent Worker must report to the Network Controller that equipment has been restored.

13. References

4001 Protecting Disabled Rail Traffic

4003 Rail Traffic Integrity

Australian Code for the Transport of Dangerous Goods by Road and Rail (ADG Code)©

Automatic Air Brake Instructions

14. Effective Date

21 November 2022