

Network Safeworking Rules and Procedures

Centralised Traffic Control System

Rule Number: 5001

Arc Infrastructure maintains the master for this document and publishes the current version on the Arc Infrastructure website. All changes and updates to the Network Safeworking Rules and Procedures are authorised by the Arc Infrastructure Rule Book Committee. This document is uncontrolled when printed.

Document History

| Version | Effective Date | Pages updated | Reasons for change |
|---------|----------------|---------------|--------------------|
| 2.0 | 03 02 2020 | All | Major Review |

Table of Contents

| | | |
|----|--|---|
| 1. | Purpose..... | 3 |
| 2. | General | 3 |
| 3. | Proceed Authorities..... | 3 |
| 4. | Failure of Control Functions | 4 |
| 5. | Entering Signalled Track from Non-Signalled Location | 4 |
| 6. | References..... | 4 |
| 7. | Effective Date..... | 4 |

1. Purpose

The purpose of this rule is to describe the operation of the *Centralised Traffic Control (CTC) System of Safeworking* used in the *Network*.

2. General

The *CTC* system comprises:

- a *Location* for the control of *Points* and signals;
- *Controlled Absolute Signals* at the entrance to each *Section*;
- *Controlled Absolute Signals* protecting the *Route* through *Interlockings*;
- *Absolute Signals (Intermediate Signals)* to divide *Sections* into multiple *Blocks*; and
- *Track-Circuits* or *Axle Counters*.

Sections within the *Centralised Traffic Control (CTC) Territory* consist of single or multiple lines that are *Uni-Directional* or *Bi-Directional*.

Interlocking of *Track-Circuits*, *Axle Counters*, *Points* and *Protecting Signals* prevent a *Running Signal* from displaying a PROCEED indication unless:

- the *Block* beyond the signal is not *Occupied*;
- there are no conflicting *Routes* set; and
- the *Points* are correctly set.

The *Network Controller* controls the entry of *Rail Traffic* into *Sections* and through *Interlockings*.

If the *CTC* system is reported as, or suspected to be, faulty or unreliable, a method of *Special Working* must be used until the system has been restored.

3. Proceed Authorities

The authority for *Rail Traffic* to enter and occupy a *Block* under the *CTC* system is:

- a PROCEED signal;
- a verbal *Authority*; or
- a written *Authority*.

4. Failure of Control Functions

If the function to control *Points* and signals fail, the *Network Controller* must instruct the *Competent Worker* to:

- confirm the setting of *Points*;
- manually operate the *Points* as required; and
- manually *Secure* the *Points*, if necessary.

The *Rail Traffic Crew* must obtain an authority to pass *Fixed Signals* at STOP in accordance with Rule 6013 Passing Fixed Signals at STOP.

5. Entering Signalled Track from Non-Signalled Location

Where there is no *Fixed Signal* to control entry into *Centralised Traffic Control (CTC) Territory*, the *Network Controller* must authorise *Rail Traffic* entry.

The *Network Controller* must:

- verify that there are no conflicting *Rail Traffic* movements or *Track Occupancies*,
- where provided, give the release for *Switchlock* operation; and
- give permission for the *Points* to be operated.

Rail Traffic entering from non-signalled areas must be prepared to stop at the next *Fixed Signal* and comply with the indication displayed.

6. References

6013 Passing Fixed Signals at STOP

7. Effective Date

3 February 2020